ASSEMBLY INSTRUCTION

Thank You

FOR CHOOSING FELTON INDUSTRIES


ECO-TREND SHELTERED PARK SETTING [Code No:FELETSP]




"This product has been manufactured in Australia to the highest quality standard. guaranteeing proven quality, durability and low maintenance"















Felton Industries Pty Ltd | ABN: 17 130 687 240




WARNING: This assembly required two or more people as lifting is involved. Please ensure bolts and nuts are only finger-tightened throughout assembly for flexibility in lining up components. Bolt and nuts should be securely tightened in place when instructed to do so. Please check all components are included before proceeding with the

	T	
ITEM	DESCRIPTION	Qty
1	FELETSP_MAIN FRAME	1
2	FELETSP_MAIN FRAME 2	1
3	FELETSP_CONNECTION BAR	1
4	FELETSP_SEAT PLANK L2315	2
5	FELETSP_TABLE PLANK L2020	3
6	FELETSP_ROOF	2
7	AS-NZS 2465 Bolt - 1/2" x 3.5"	8
8	AS-FLAT WASHER - 1/2"	4
9	AS-NZS NYLON Nut - 1/2"	12
10	AS-NZS 2465 Bolt - 1/4" x 1"	24
11	AS-NZS NYLON Nut - 1/4"	40
12	AS-NZS 2465 Bolt - 1/2" x 6"	40






Attach the two main frames 1 and 2 to the connection bar 3 by using bolts 7, washes 8 and nuts **9**. Note that frame tags facing inward.




Install three table planks 6 onto frame fixing plates as illustrated. Fasten the table planks 6 with hexagonal bolts

and nuts




Install two seat planks **4** onto frame fixing plates as illustrated. Fasten the seat planks 4 with hexagonal bolts **(1)** and nuts **(11)**


6



Attach the upper roof **6** to the main frame **1** and **2**. Fasten the upper roof **6** with hexagonal bolts 12, washers 8 and nuts 9



Repeat step 4 with the other roof at lower position



Tighten all hexagonal head bolts with spaners and appropriate tools. Then attach the whole assembly to the ground by using dyna-bolts preferably, on each frame lug