

# ASSEMBLY INSTRUCTION

Thank You

FOR CHOOSING FELTON INDUSTRIES

MODULAR BREAK SHELTER  
[Code No: FELMBRS]



"This product has been manufactured in Australia to the highest quality standard, guaranteeing proven quality, durability and low maintenance"



1800 22 00 55

sales@felton.net.au

1800 05 91 58

www.felton.net.au


**felton**  
INDUSTRIES

Felton Industries Pty Ltd | ABN: 17 130 687 240




**WARNING:** This assembly required two or more people as lifting is involved. **Please ensure bolts and nuts are only finger-tightened throughout assembly for flexibility in lining up components.** Bolt and nuts should be securely tightened in place when instructed to do so. Please check all components are included before proceeding with the assembly

ITEM	DESCRIPTION	Qty
1	FELMBST_CROSS BAR	1
2	FELMBST_UPRIGHT BAR	1
3	FELMBST_LEFT FRAME	1
4	FELMBST_RIGHT FRAME	1
5	FELMBST_BACK PANEL	2
6	FELMBST_ROOF	1
7	FELMBST_LEG SUPPORT	2
8	FELMBST_SEAT PLANK L1800	1
9	AS-NZS 2465 Bolt - 0.5in x 3in	2
10	AS-Flat Washer - 0.5in	20
11	AS-NZS Nylon Nut - 0.5in	10
12	AS-NZS 2465 Bolt - 0.5in x 3.5in	4
13	AS-NZS 2465 Bolt - 0.5in x 4in	4
14	AS-NZS 2465 Bolt - 0.375in x 3in	3
15	AS-Flat Washer - 0.375in	18
16	AS-NZS Nylon Nut - 0.375in	9
17	AS-NZS 2465 Bolt - 0.375in x 3.5in	6
18	AS-NZS 2465 Bolt - 0.25in x 1in	8
19	AS-NZS Nylon Nut - 0.25in	8




1




Attach cross bar (1) to upright bar (2) by using bolts (9), washers (10) and nuts (11) as illustrated.

2




Attach left frame (3) and right frame (4) to the assembly in step 1 by using bolts (13), washers (10) and nuts (11) as illustrated.

3




Attach two back panels (5) to the assembly in step 2 by using bolts (14), bolts (17), washers (15) and nuts (16) as illustrated.

4




Attach the top roof (6) to the assembly in step 3 by using bolts (12), washers (10) and nuts (11) as illustrated.

5



Attach seat plank (8) to two leg supports (7) by using bolts (18) and nuts (19) as illustrated.

6



Tighten all hexagonal head bolts with spanners and appropriate tools. Then attach the frame and seating assemblies to the ground by using M12 dyna-bolts preferably, on each frame lug.